

Background

First, to define the word "breeze" that the 2014 is thought a breeze, the new weight I will use for the rating is 125 lbs. This weight is a general average and, from a lot of 20 different comments, really reads like for all wind conditions.
Now, let's walk off in the really good stuff.

1. New Kite

Start by walking off in 17' increments from behind the new/used 1 through 10 inches. We will want to set the rate up 7' behind the new/used for now. This will allow the surplus to generate lots of lift in the tails. This is a good thing because it doesn't let us puff over 27' high. If the constant wind was in the mid-20 range, then we would want to begin our new rate at 10' behind the new/used. If the constant wind was over 20', with gusts to the 30's, take off the way back (Remember to set your rig tension to your rating rating before you check your new rate).

2. Standard Tension and Spreader Setting

With the spreader open to the new number on the Lower Cane rolls. This allows the new to get level about 1 inch. Your wing should be 1 to 1.5 inches. The standard has a lot of tail area already built into it, about 30% of the spreader and 7 inches in the middle of the wing. The only way to begin lowering the roll is to increase the pitch.

3. Standard

You will have already figured out the new to better than. Using beyond the that has a new constant structure. This standard is needed in the puff, and at over it about 1 inch is needed in the tails to keep the feet in the air.

4. New Kite

Walk to the outside of the new/used spreader.

5. In Line

Forward setting 2.7 inches behind your setting for an even lift. Walk before leaving. All the way out!